



105 Bonnie Drive  
Butler, PA 16002  
724-283-4681  
724-283-5939 (fax)  
[www.bwieagle.com](http://www.bwieagle.com)

## PRODUCT INFORMATION BULLETIN

### AIR-EAGLE® XLT

900MHz 8 Input Transmitter

**MODEL 44-1800-DCI-DC**

#### DESCRIPTION

The AIR-EAGLE XLT, MODEL 44-1800-DCI-DC is an R.F. transmitter capable of sending eight 5-24VDC input commands to an Air-Eagle XLT Receiver. Any number of transmitters and receivers can be combined to create a long range radio frequency system that operates hazardous or hard-to-reach electrical apparatus from safe, convenient locations of up to 2500 feet away (Up to 2 mile range with optional antennas). This unit is user-programmable for up seven network frequencies to allow multiple systems to operate simultaneously in the same area without interference.

#### INSTALLATION

DISCONNECT Power from all equipment before installation.


1. Mount the transmitter in a convenient location.
2. Install input wiring to TER1
3. Attach supplied rubber duck antenna to TNC connector on the right side of the unit.
4. Connect DC power to the proper terminals in your control circuit.

#### TERMINAL STRIP WIRING

1	(-) 9-36VDC
2	(+) 9-36VDC
3	Input 1 – 5-24VDC (-)
4	Input 1 – 5-24VDC (+)
5	Input 2 – 5-24VDC (-)
6	Input 2 – 5-24VDC (+)
7	Input 3 – 5-24VDC (-)
8	Input 3 – 5-24VDC (+)
9	Input 4 – 5-24VDC (-)
10	Input 4 – 5-24VDC (+)
11	Input 5 – 5-24VDC (-)
12	Input 5 – 5-24VDC (+)
13	Input 6 – 5-24VDC (-)
14	Input 6 – 5-24VDC (+)
15	Input 7 – 5-24VDC (-)
16	Input 7 – 5-24VDC (+)
17	Input 8 – 5-24VDC (-)
18	Input 8 – 5-24VDC (+)



#### CONTROLS & INDICATORS



POWER/TX LED	Illuminated green when power is applied. Changes to red when transmitting data.
Inputs 1 thru 8	Eight 5-24VDC inputs
SEL1	Dip switch bank for selecting operating frequency
RF1	RF module that transmits data to the remote receiver

# AIR-EAGLE® XLT

## 900MHz 8 Input RF Transmitter

### MODEL 44-1800-DCI-DC

#### FREQUENCY SET-UP

This transmitter is shipped with the SEL1 switches in the open positions and is operating on Frequency 1. If you wish to change the default frequency setting, follow the instructions below:

1)	Remove power from unit		
2)	Remove top cover.		
3)	Select network frequency using table below.		
4)	Reattach cover and apply power.		
5)	Programming is now complete.		
SEL1 (SW1-3): (NETWORK FREQUENCY)	Network Frequency      SW1      SW2      SW3		
1	OPEN	OPEN	OPEN
2	CLOSED	OPEN	OPEN
3	OPEN	CLOSED	OPEN
4	CLOSED	CLOSED	OPEN
5	OPEN	OPEN	CLOSED
6	CLOSED	OPEN	CLOSED
7	OPEN	CLOSED	CLOSED
SEL1 (SW4)	Reserved for future use		

#### SPECIFICATIONS

DC Input	9 - 36 VDC @ 10 Watts
Fuse Protected	1 amp
RF Frequency	900MHz Spread Spectrum
Input Channels	Eight 5-24VDC Inputs
RF Output Power	250 mW
Transmitter Range	Approximately 2500 Feet w/standard antenna
Transmitter Frequencies	7 Independent Network Frequencies
Antenna Connection	TNC Bulkhead
Enclosure	Polycarbonate, IP66 (NEMA 4)
Operating Temperature	-40° F to +185° F

#### REPLACEMENT PARTS & ACCESSORIES


PC Board (Main)	44-1802-DCI-DC
Standard Antenna (Included):	
900MHz Portable Antenna (For distances up to 2500 feet*)	49-1103
Optional Antennas and Accessories:	
900MHz Omni Directional Antenna (For distances up to 2 miles*)	49-3101
900MHz 13dB Yagi Antenna Long Range Operation (For distances up to 4 miles*)	49-3102
Flex Coax Cable w/Connectors	49-4000-XX (XX = # of Feet)

\* = Line of Sight

#### APPROVALS

United States (FCC)	MCQ-XB900HP
Canada (IC)	1846A-XB900HP

#### DIMENSIONS



**AIR-EAGLE® XLT**  
**900MHz 8 Input RF Transmitter**  
**MODEL 44-1800-DCI-DC**

**LIMITED WARRANTY STATEMENT**

BWI Eagle Inc. warrants the Air-Eagle Remote Control System, if properly used and installed, will be free from defects in material and workmanship for a period of 1 year after date of purchase. Said warranty to include the repair or replacement of defective equipment. This warranty does not cover damage due to external causes, including accident, problems with electrical power, usage not in accordance with product instructions, misuse, neglect, alteration, repair, improper installation, or improper testing. This limited warranty, and any implied warranties that may exist under state law, apply only to the original purchaser of the equipment, and last only for as long as such purchaser continues to own the equipment. This warranty replaces all other warranties, express or implied including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. BWI Eagle makes no express warranties beyond those stated here. BWI disclaims without limitation, implied warranties of merchantability and fitness for a particular purpose. Some jurisdictions do not allow the exclusion of implied warranties so this limitation may not apply to you. To obtain warranty service, contact BWI Eagle for a return material authorization. When returning equipment to BWI Eagle, the customer assumes the risk of damage or loss during shipping and is responsible for the shipping costs incurred.

---

DOCUMENT DATE: 03/01/2019 / PRODUCT REV. 5

---



105 Bonnie Drive  
Butler, PA 16002  
(724) 283-4681  
Fax (724) 283-5939  
[www.bwieagle.com](http://www.bwieagle.com)